

**CANbox<sup>®</sup>**

**Dual CAN to WLAN/LAN Converter**

# The CANbox®

<b>1</b>	<b>GENERAL INFORMATION.....</b>	<b>5</b>
1.1	SPECIAL FEATURES.....	5
1.2	INSTALLED MAX MODULES.....	5
1.3	EXTERNAL CONNECTORS.....	6
1.4	WLAN/LAN PROPERTIES.....	6
1.4.1	WLAN.....	6
1.4.2	Transfer rates.....	7
<b>2</b>	<b>CONNECTORS OF THE CANBOX®.....</b>	<b>7</b>
2.1	OVERVIEW.....	7
2.2	ASSIGNMENT OF THE EXTERNAL CONNECTORS.....	8
2.2.1	Connector ST 1, power supply.....	8
2.2.2	Host Interfaces (Connectors ST 2 and ST 3).....	8
2.2.3	D-SUB-9 plug for CAN 1 and CAN 2.....	9
2.2.4	SMA plug for antenna.....	9
<b>3</b>	<b>STARTING INSTRUCTIONS.....</b>	<b>10</b>
3.1	CANBOX® SETUP.....	10
3.2	CANBOX® CONFIGURATION TOOL (WINDOWS 32).....	11
3.2.1	Operation.....	11
3.2.2	CANbox® Configuration menu.....	12
3.2.3	Configuration dialog.....	13
3.2.4	Device properties dialog.....	14
3.3	FIRST CONNECTION TO A NEW CANBOX®.....	15
3.3.1	Connect via LAN.....	15
3.3.2	Connect via serial interface.....	15
3.4	POCKET PC 2003.....	16
3.5	CONFIGURATION EXAMPLES.....	17
3.5.1	Configuration example for Windows XP.....	17
3.5.2	Configuration example for POCKET PC 2003.....	18
3.6	CANBOX® AS ROUTER.....	19
3.6.1	Configuration examples.....	21
3.7	ENHANCED ROUTER (FORWARDER).....	23
3.7.1	Configuration examples.....	23
3.8	ACCEPTANCE FILTER CALCULATOR.....	24
3.9	AUTOMATIC RECOVERY ON HEAVY CAN BUS IN ROUTER MODE.....	26
<b>4</b>	<b>CANBOX® LIBRARY.....</b>	<b>27</b>
4.1	STRUCTURES AND DEFINITIONS.....	27
4.1.1	CANBOX_VERSION_INFO.....	27
4.1.2	CANBOX_TIME_STAMP.....	27
4.1.3	CANBOX_SCAN_INFO.....	27
4.1.4	CANBOX_DEVICE_INFO.....	28
4.1.5	CANBOX_RESET_EX.....	28
4.1.6	CANBOX_INTERFACE.....	29
4.1.7	CANBOX_INTERFACE_EX.....	30
4.1.8	CANBOX_INTERFACE_STATE.....	31
4.1.9	CANBOX_INTERFACE_INFO.....	32
4.1.10	CANBOX_INTERFACE_READ.....	32
4.1.11	CANBOX_INTERFACE_WRITE.....	32
4.1.12	CANBOX_IDENTIFIER.....	33
4.1.13	CANBOX_ACCEPTANCE_FILTER.....	33

4.1.14	CANBOX_ROUTER.....	34
4.1.15	CANBOX_ROUTER_EX.....	35
4.1.16	CANBOX_LAN_CONFIG.....	36
4.1.17	CANBOX_WLAN_CONFIG.....	36
4.1.18	CANBOX_IDENTIFIER_DATA.....	37
4.1.19	CANBOX_UNIVERSAL_SENDER_DATA.....	37
4.1.20	CANBOX_16.....	37
4.1.21	CANBOX_32.....	38
4.2	ERROR CODES.....	39
4.2.1	General error messages of the CANbox®.....	39
1.1.1.	Error messages concerning initialization.....	39
1.1.2.	Error messages concerning release.....	39
1.1.3.	Error messages concerning CAN interfaces.....	39
1.1.4.	Error messages concerning CAN Identifier.....	39
1.1.5.	Error messages concerning acceptance filters.....	40
1.1.6.	Error messages concerning universal senders.....	40
1.1.7.	General error messages of the library.....	40
1.1.8.	Error messages of the library concerning the connection to the CANbox®.....	40
4.3	GENERAL FUNCTIONS.....	41
4.3.1	canbox_init_lib.....	41
4.3.2	canbox_get_driver_version.....	41
4.3.3	canbox_get_error_message.....	41
4.3.4	canbox_exit_lib.....	41
4.4	DEVICE FUNCTIONS.....	42
4.4.1	canbox_scan_devices.....	42
4.4.2	canbox_get_device_parameter.....	42
4.4.3	canbox_open_device.....	42
4.4.4	canbox_reset_device.....	42
4.4.5	canbox_reset_device_ex.....	43
4.4.6	canbox_get_device_info.....	43
4.4.7	canbox_reset_time_stamp.....	43
4.4.8	canbox_set_time_stamp.....	43
4.4.9	canbox_set_time_stamp_by_ref.....	43
4.4.10	canbox_close_device.....	44
4.5	INTERFACE FUNCTIONS.....	44
4.5.1	canbox_get_interface_info.....	44
4.5.2	canbox_open_interface.....	44
4.5.3	canbox_open_interface_by_ref.....	44
4.5.4	canbox_open_interface_ex.....	45
4.5.5	canbox_open_interface_ex_by_ref.....	45
4.5.6	canbox_get_interface_state.....	45
4.5.7	canbox_get_last_interface_time.....	45
4.5.8	canbox_clear_interface.....	46
4.5.9	canbox_start_interface.....	46
4.5.10	canbox_read_interface.....	46
4.5.11	canbox_read_interface_ex.....	46
4.5.12	canbox_write_interface.....	47
4.5.13	canbox_write_interface_ex.....	47
4.5.14	canbox_stop_interface.....	47
4.5.15	canbox_close_interface.....	47
4.6	IDENTIFIER FUNCTIONS.....	48
4.6.1	canbox_open_identifier.....	48
4.6.2	canbox_open_identifier_by_ref.....	48
4.6.3	canbox_read_identifier.....	48
4.6.4	canbox_write_identifier.....	48
4.6.5	canbox_close_identifier.....	49
4.7	ACCEPTANCE FILTER FUNCTIONS.....	49
4.7.1	canbox_open_acceptance_filter.....	49
4.7.2	canbox_open_acceptance_filter_by_ref.....	49
4.7.3	canbox_read_acceptance_filter.....	49

4.7.4	<i>canbox_close_acceptance_filter</i> .....	50
4.8	UNIVERSAL SENDER FUNCTIONS.....	50
4.8.1	<i>canbox_open_universal_sender</i> .....	50
4.8.2	<i>canbox_write_universal_sender</i> .....	50
4.8.3	<i>canbox_write_universal_sender_ex</i> .....	50
4.8.4	<i>canbox_close_universal_sender</i> .....	51
4.9	ROUTER FUNCTIONS.....	51
4.9.1	<i>canbox_read_router_config</i> .....	51
4.9.2	<i>canbox_read_router_config_ex</i> .....	51
4.9.3	<i>canbox_write_router_config</i> .....	51
4.9.4	<i>canbox_write_router_config_ex</i> .....	52
4.10	SUPPORTING FUNCTIONS FOR VISUAL BASIC.....	52
4.10.1	<i>canbox_convert_to_CANbox16</i> .....	52
4.10.2	<i>canbox_convert_to_CANbox16_by_ref</i> .....	52
4.10.3	<i>canbox_convert_from_CANbox16</i> .....	52
4.10.4	<i>canbox_convert_to_CANbox32</i> .....	53
4.10.5	<i>canbox_convert_to_CANbox32_by_ref</i> .....	53
4.10.6	<i>canbox_convert_from_CANbox32</i> .....	53
<b>5</b>	<b>SOCKET INTERFACE</b> .....	<b>54</b>
5.1.	STRUCTURES AND DEFINITIONS.....	54
5.1.1	<i>CANBOX_SOCKET_IN</i> .....	54
5.1.2	<i>CANBOX_SOCKET_OUT</i> .....	54
5.2	FUNCTIONS.....	55
5.2.1	<i>canbox_init (Index 4)</i> .....	55
5.2.2	<i>canbox_reset (Index 5)</i> .....	55
5.2.3	<i>canbox_info (Index 6)</i> .....	55
5.2.4	<i>canbox_set_time_stamp (Index 7)</i> .....	55
5.2.5	<i>canbox_exit (Index 12)</i> .....	56
5.2.6	<i>canbox_open_interface (Index 15)</i> .....	56
5.2.7	<i>canbox_open_interface_ex (Index 16)</i> .....	56
5.2.8	<i>canbox_get_interface_state (Index 17)</i> .....	56
5.2.9	<i>canbox_start_interface (Index 18)</i> .....	57
5.2.10	<i>canbox_clear_interface (Index 19)</i> .....	57
5.2.11	<i>canbox_read_interface (Index 20)</i> .....	57
5.2.12	<i>canbox_write_interface (Index 21)</i> .....	57
5.2.13	<i>canbox_stop_interface (Index 22)</i> .....	57
5.2.14	<i>canbox_close_interface (Index 23)</i> .....	58
5.2.15	<i>canbox_open_identifier (Index 25)</i> .....	58
5.2.16	<i>canbox_read_identifier_buffer (Index 26)</i> .....	58
5.2.17	<i>canbox_read_identifier_actual (Index 27)</i> .....	58
5.2.18	<i>canbox_write_identifier (Index 28)</i> .....	58
5.2.19	<i>canbox_close_identifier (Index 29)</i> .....	59
5.2.20	<i>canbox_open_filter (Index 30)</i> .....	59
5.2.21	<i>canbox_read_filter_buffer (Index 31)</i> .....	59
5.2.22	<i>canbox_read_filter_actual (Index 27)</i> .....	60
5.2.23	<i>canbox_close_filter (Index 32)</i> .....	60
5.2.24	<i>canbox_open_sender (Index 13)</i> .....	60
5.2.25	<i>canbox_write_sender (Index 24)</i> .....	60
5.2.26	<i>canbox_close_sender (Index 14)</i> .....	60
5.2.27	<i>canbox_read_router_config (Index 34)</i> .....	61
5.2.28	<i>canbox_write_router_config (Index 35)</i> .....	61
5.2.29	<i>canbox_read_lan_config (Index 36)</i> .....	61
5.2.30	<i>canbox_write_lan_config (Index 37)</i> .....	61
5.2.31	<i>canbox_read_wlan_config (Index 38)</i> .....	61
5.2.32	<i>canbox_write_wlan_config (Index 39)</i> .....	62
<b>6</b>	<b>TECHNICAL DATA</b> .....	<b>62</b>

# 1 General Information

The CANbox<sup>®</sup> is a dual CAN to WLAN/LAN converter with two high-speed CAN interfaces (up to 1 MBit/s) that are compliant to CAN specification 2.0A and 2.0B. Fault-tolerant low-speed interfaces are available as an option. The connection to the CANbox<sup>®</sup> can be established via a serial interface, LAN or WLAN. The included software of the CANbox<sup>®</sup> is described in chapters 3 and 4. Drivers are available for Win32- and Pocket PC 2003-operating systems. Furthermore the socket interface can be used for a direct communication using the TCP/IP socket platform (requires at least firmware version 3.A).



Up to 10 CANboxes can be used simultaneously on a single PC or PDA.

The metal enclosure of the CANbox<sup>®</sup> measures only 113 x 83 x 33 mm. The CANbox<sup>®</sup> can be fixed either on DIN-rails or with bolts on any plain surface in case of stationary use. Power supply for the CANbox<sup>®</sup> is tailored to automotive and industry requirements. The voltage range is 6...60V (DC) which covers all automotive voltages (incl. 42V). The power supply is not galvanically insulated. Galvanic isolation of the CAN buses is achieved with the SORCUS standard I/O module X-CAN-2i.

## 1.1 Special Features

- Intelligent, decentralized, autonomous system
- Interface-converter CAN to WLAN/LAN
- WLAN on-board
- Dimensions 113 x 83 x 33 mm
- Power supply: 6,0V...60V
- Mountable on DIN-rails or plain surfaces (Holder available optionally)


## 1.2 Installed MAX Modules

The device has two module-slots for MAX modules. The slots are equipped as described below.


Slot-No.	Module	Function	Explanation
1	X-MAX-E	CPU module with Ethernet	This slot is used for a CPU module.
2	X-CAN-2i/H	2 CAN-channels with high speed drivers	Optionally, 2 fault-tolerant CAN channels or mixed are possible

## 1.3 External connectors

Front view



Back view



## 1.4 WLAN/LAN properties

### 1.4.1 WLAN

The WLAN standard 802.11b offers up to 14 channels depending on the region. It has to be considered that not all channels are free from overlap. If more than one WLAN network is used in the same area, different channels should be used with 4 channels free between the two channels.

Channel	Center frequency	Frequency range
1	2412 MHz	2399.5 MHz – 2424.5 MHz
2	2417 MHz	2404.5 MHz – 2429.5 MHz
3	2422 MHz	2409.5 MHz – 2434.5 MHz
4	2427 MHz	2414.5 MHz – 2439.5 MHz
5	2432 MHz	2419.5 MHz – 2444.5 MHz
6	2437 MHz	2424.5 MHz – 2449.5 MHz
7	2442 MHz	2429.5 MHz – 2454.5 MHz
8	2447 MHz	2434.5 MHz – 2459.5 MHz
9	2452 MHz	2439.5 MHz – 2464.5 MHz
10	2457 MHz	2444.5 MHz – 2469.5 MHz
11	2462 MHz	2449.5 MHz – 2474.5 MHz
12	2467 MHz	2454.5 MHz – 2479.5 MHz
13	2472 MHz	2459.5 MHz – 2484.5 MHz
14	2484 MHz	2471.5 MHz – 2496.5 MHz

*WLAN channels and their frequencies*

The distance range of a WLAN device is typically up to 30m inside (100m maximum) and 100m outside (maximum 300m).

### 1.4.2 Transfer rates

The following table shows the achieved transfer rates with the CANbox® in dependence of the transfer types. The CANbox® was **running idle** and the distance between the PC and the CANbox® was about 1m. This specification is meant to be as a guideline only.

Type of transfer	Transfer rate
Connection with WLAN-PC using AdHoc	140 kB/s
Connection with WLAN-PC using an AccessPoint	90 kB/s
Connection with LAN-PC using an AccessPoint	195 kB/s
Connection with LAN-PC via LAN	250 kB/s

## 2 Connectors of the CANbox®

### 2.1 Overview

The following external connectors are present:


Connector	Type	Function
ST1	M8-Connector 4 pins	Power supply (6..60V)
ST2	M8-Connector 4 pins	Ethernet interface
ST3	M8-Connector 3 pins	Serial interface
CAN 1	D-SUB-9 male	CAN bus 1
CAN 2	D-SUB-9 male	CAN bus 2
WLAN	SMA female	WLAN antenna

## 2.2 Assignment of the external connectors

The power supply and the host interfaces are connected by connectors of type M8. The cable with 3- or 4-pin plug in 2m and 5m length are available from many distributors. The cable with 2m length are also available from SORCUS. In addition, SORCUS offers cable equipped with D-SUB-9 socket for serial connection and with RJ45 plug for direct connection of Ethernet on a company network or a PC (Cross-Over).

The cable uses the following color assignment:

Color	3 Pin	4 Pin
Brown	1	1
White	-	2
Black	2	3
Blue	3	4




View of  
M8 plug  
from outside

The cable of the Hirschmann company have the following type designation:

- Cable M8 3 pins: ELKA-KV 3308
- Cable M8 4 pins: ELKA-KV 4408

Cables of other manufacturers (Binder, Phoenix etc.) use different declarations.



### 2.2.1 Connector ST 1, power supply

At M8 plug ST1, the power supply of the CANbox<sup>®</sup> has to be applied. Contacts 3 and 4 are to be used for connecting GND, contacts 1 and 2 supports power supplies with voltages from 6...60V. If the power supply is connected the wrong way a fuse will brake inside of the CANbox<sup>®</sup> which may be replaced by the SORCUS service only.


ST1	Signal	Cable Color
1,2	+Vbatt	Brown, White
3,4	-Vbatt (=XGND)	Black, Blue

Because of the integrated DC/DC converter, the current consumption is higher when using small input voltages than high input voltages.

### 2.2.2 Host Interfaces (Connectors ST 2 and ST 3)

#### 2.2.2.1 Assignment Connector ST 2, M8 plug with 4 pins (Ethernet):

ST 2	Signal of CPU modul	Signal	RJ45 for Hub PC
1	Connector A Pin 1	TX+	1 3






2	Connector A Pin 2	TX-	2	6
3	Connector A Pin 3	RX+	3	1
4	Connector A Pin 4	RX-	6	2

The assignment of the RJ45 plug is given for a connection to a hub and for direct connection to a PC.

#### 2.2.2.2 Assignment Connector ST 3, M8 plug with 3 pins (serial host interface):

ST 3	Signal of CPU modul	Signal	Pin at D-SUB-9
1	Connector A Pin 8	TXD	2
2	Connector A Pin 6	RXD	3
3	ST5 Pin 10	XGND	5



The assignment for the D-SUB-9 socket is given for direct connection to a PC.

### 2.2.3 D-SUB-9 plug for CAN 1 and CAN 2

The two CAN interfaces are galvanically isolated from each other and from the rest of the CANbox®. The options of the CAN interfaces are described in the software part of this manual.

D-SUB-9 plug for CAN channel 1	
Signal	Pin D-SUB
CAN1-GND	3
CAN1-L	2
CAN1-H	7

D-SUB-9 plug for CAN channel 2	
Signal	Pin D-SUB
CAN2-GND	3
CAN2-L	2
CAN2-H	7

### 2.2.4 SMA plug for antenna

At the back side of the CANbox® there is a SMA plug connector for a WLAN antenna. Here, various types of antennas can be connected. The following antennas are available among others:

- Short antenna (93mm) 90° angle with 2,1dBi gain
- Table antenna (190mm height) with 1,8m cable, 5dBi gain

## 3 Starting Instructions

### 3.1 CANbox<sup>®</sup> Setup

The CANbox<sup>®</sup> setup named CANbox.exe is to be used for the installation of the different components which are available for CANbox<sup>®</sup> operation. After the installation is started, a dialog for selection of the components appears. The following components are available:

- Win32 driver: Driver and configuration tool for CANbox<sup>®</sup> administration with Win32 operating systems
- Win32 library: Library for programming CANbox<sup>®</sup> access with Win32 operating systems (C, C++, VB6.0, VB.NET)
- Win32 samples: Examples for programming the CANbox<sup>®</sup> with Win32 operating systems
- Win32 tools: Tools for using the CANbox<sup>®</sup> with Win32 operating systems
- POCKET PC 2003 driver: Driver and configuration tool for CANbox<sup>®</sup> administration with POCKET PC 2003 operating systems
- POCKET PC 2003 SE driver: Driver and configuration tool for CANbox<sup>®</sup> administration with POCKET PC 2003 SE operating systems
- POCKET PC 2003 library: Library for programming CANbox<sup>®</sup> access with POCKET PC 2003 (SE) operating systems (C, C++, VB6.0, VB.NET)
- POCKET PC 2003 samples: Examples for programming the CANbox<sup>®</sup> with POCKET PC 2003 (SE) operating systems
- POCKET PC 2003 tools: Tools for using the CANbox<sup>®</sup> with POCKET PC 2003 (SE) operating systems
- Documentation: Documentation of the CANbox<sup>®</sup>


After the selection of the components, a path dialog for destination path selection appears. The selected components will be installed in sub directories of the selected path. The driver and the configuration tool will be installed in designated windows directories. After path selection, the installation of the components takes place.

## 3.2 CANbox<sup>®</sup> Configuration Tool (Windows 32)

### 3.2.1 Operation

The CANbox<sup>®</sup> Configuration Tool serves for administration and configuration of the CANbox<sup>®</sup>es. It is installed in the control panel with the name **CANbox<sup>®</sup>**.

It contains a list of the installed CANboxes where each CANbox<sup>®</sup> is assigned an unique ID. This ID is needed for the configuration of the router mode for example.



The screenshot shows a window titled "CANbox (Firmware 4.A)" with a menu bar containing "Device" and "Settings". Below the menu bar is a table with the following data:

Board ID	Board Type	State	Parameter
0	CANbox	Active	192.168.0.240
1	CANbox	Active	192.168.0.241
2	CANbox	Active	192.168.0.242
3	CANbox	Active	192.168.0.243
4	CANbox	Active	192.168.0.250
5	CANbox	Active	192.168.0.251
6	CANbox	Active	192.168.0.252
7	CANbox	Active	192.168.0.253
8			
9	CANbox	Active	COM3


*CANbox<sup>®</sup> configuration at Win32 operating systems*

After selecting an empty line, a CANbox<sup>®</sup> can be installed via the **Device** menu of the main menu respectively the context menu of the CANbox<sup>®</sup>; a double click on a installed CANbox<sup>®</sup> makes its configuration possible.

Moreover, a connection to a CANbox<sup>®</sup> is possible, if the communication parameter correspond with the configuration. After a successful connection, the communication parameters and some other settings can be changed. The changes take effect after restarting the CANbox<sup>®</sup>.

The configuration of the CANbox<sup>®</sup> can also take place by using the serial interface. Here, a cross over connection between a serial interface of the PC and the serial interface of the CANbox<sup>®</sup> is required.

### 3.2.2 CANbox<sup>®</sup> Configuration menu



CANbox<sup>®</sup> configuration menu

The CANbox<sup>®</sup> configuration menu provides the following options:

#### 3.2.2.1 Create

Install a CANbox<sup>®</sup>. This command opens the configuration dialog. (3.2.3)

#### 3.2.2.2 Remove

Uninstall a CANbox<sup>®</sup>.

#### 3.2.2.3 Connect

Connect with a CANbox<sup>®</sup> with configured parameters. This command opens the device properties dialog. (3.2.4)

#### 3.2.2.4 Connect via COM port...

Connect a CANbox<sup>®</sup> using a serial interface. The interface is configured in the menu command "settings". This command opens the device properties dialog. (3.2.4)

#### 3.2.2.5 Reset Router Configuration

Delete the router configuration from the selected CANbox<sup>®</sup>. The changes take effect on the next restart of the CANbox<sup>®</sup>.


#### 3.2.2.6 Reset Router Configuration via COM port

Delete the router configuration from the selected CANbox<sup>®</sup> using a serial interface. The interface is configured in the menu command "settings".

#### 3.2.2.7 Properties...

Edit the configuration of the selected CANbox<sup>®</sup>. This command opens the configuration dialog. (3.2.3)

### 3.2.3 Configuration dialog



CANbox<sup>®</sup> Configuration dialog

In this dialog a connection to a CANbox<sup>®</sup> can be configured. The following parameters can be configured.

#### Connection active:

This command activates or deactivates the connection. If the connection is deactivated a connection to the chosen CANbox<sup>®</sup> is not possible.

#### Timeout:

In this field the connection timeout can be entered in ms.

#### Connection Type:

Either “TCP/IP Connection” or “Serial Connection” can be selected.


#### IP-address:

In this field the IP-Address configured in the CANbox<sup>®</sup> must be entered. The default value is 192.168.0.240.

#### Serial port:

Selection of the serial port on the computer to connect to the CANbox<sup>®</sup>.

### 3.2.4 Device properties dialog



CANbox<sup>®</sup> Device properties dialog at Win32 operating systems

#### 3.2.4.1 General

This property page shows general information about the CANbox<sup>®</sup> and versions of the installed drivers. If the firmware of the CANbox<sup>®</sup> is older than the configuration tool, a firmware update can be done by activating the check box **Update Firmware**. After pressing the OK button, the firmware is transferred into the CANbox<sup>®</sup> and will be activated after a restart of the CANbox<sup>®</sup>.

#### 3.2.4.2 LAN

The property page LAN offers all necessary parameters for a conventional LAN connection:

Element	Meaning	Default
IP-Address	IP address of the CANbox <sup>®</sup>	192.168.0.240
Subnetmask	Subnetmask of the CANbox <sup>®</sup>	255.255.255.000

Changes of these parameters will be activated by restarting the CANbox<sup>®</sup>.

#### 3.2.4.3 WLAN

The property page WLAN contains all needed parameters for a wireless LAN connection:

Element	Meaning	Default
IP-Address	IP address of the CANbox <sup>®</sup>	192.168.0.250
Subnetmask	Subnetmask of the CANbox <sup>®</sup>	255.255.255.000
SSID	Network name with up to 34 characters	CANbox
Mode	AdHoc connection or connection via Access Point	AdHoc
Channel	WLAN channel from 1 to 14	10
Authentication	Network authentication <i>Open System</i> or <i>Shared Key</i>	Open System

WEP-Encryption	Data encryption <i>Inactive</i> or <i>WEP</i>	Inactive
Key0	64 bits or 128 bits encryption key	
Key1	64 bits or 128 bits encryption key	
Key2	64 bits or 128 bits encryption key	
Key3	64 bits or 128 bits encryption key	
Keyld	Index of used key	0

The default parameters should be changed directly after the installation process in order to prevent not allowed access to the CANbox® by third persons.

Input and presentation of the network keys takes place in the form of a password. For guaranteeing correct input those values have to be set twice.

Changes of these parameters will be activated by restarting the CANbox®.

### 3.3 First connection to a new CANbox®

#### 3.3.1 Connect via LAN

The CANbox® factory default LAN settings are:

IP Address: 192.168.0.240

Subnetmask: 255.255.255.0

To establish a LAN connection to the CANbox please proceed as follows:

- 1) Connect the CANbox® with the LAN cable to your network.
- 2) Edit the TCP/IP settings of the LAN adapter of your PC and change the IP address to 192.168.0.10 and the Subnetmask to 255.255.255.0.
- 3) Open the CANbox® control panel and install a new CANbox® with the IP address of the new CANbox® in an empty id.
- 4) Select “Connect” in the “device” menu. The device properties dialog appears (3.2.4).
- 5) Update the LAN and/or WLAN settings as desired and save them with a click on OK. Close the CANbox® control panel.
- 6) Set the TCP/IP settings of the LAN adapter to the previous values.
- 7) After a reboot of the CANbox® you can connect with the new settings.

#### 3.3.2 Connect via serial interface


You need a serial CANbox® cable and a COM port or a serial USB adapter in the PC.

To establish a serial connection to the CANbox please proceed as follows

- 1) Connect the serial cable of the CANbox to COM port of the PC.

- 2) Open the CANbox® control panel. If you don't use COM1 select the COM port in the "Settings" menu.
- 3) Select CANbox® ID 0 and " Connect via COM port " in the "Devices" menu.
- 4) The device properties dialog (3.2.4) appears. Update the LAN and/or WLAN settings and save them with a click on OK.
- 5) After a rebooting the CANbox® you can establish a connection via LAN / WLAN.

### 3.4 POCKET PC 2003



CANbox® Configuration using POCKET PC 2003



## 3.5 Configuration examples

### 3.5.1 Configuration example for Windows XP

The following example describes the configuration for a WLAN ad hoc connection between a PC and a CANbox<sup>®</sup> with default settings. This configuration takes place without using third party software and assumes a correctly installed and active WLAN adapter. please proceed as follows

- 1) Open the network connections by selecting **Show all connections** in the menu **Connect with** of the **Start** menu
- 2) Select the **Wireless network connection** which has to be used with the CANbox<sup>®</sup> and open its property dialog (context menu - **Properties**)
- 3) Activate **Internet protocol (TCP/IP)** on the page **General** in the list **This connection uses the following elements** and push the **Properties** button
- 4) Choose the radio button **Use the following IP address**, enter a fitting **IP address** (e.g. 192.168.0.200) with **Subnetmask** (255.255.255.0) and Leave the dialog with the **OK** button.

If the network **CANbox<sup>®</sup>** at the available networks (**Wireless networks – Available networks – Show wireless networks**) is not visible, you have to create it by executing the following steps otherwise you only have to select it.

1. Switch to the page **Wireless networks** and push the button **Add**.
2. Enter CANbox into the Edit **Network name (SSID)** of the page **Assignment** and deactivate the **data encryption**. Activate the check box **This is an computer to computer network (Ad hoc)**.
3. Leave the dialog with the **OK** button.

Please pay attention that no other network uses an IP address of type 192.168.0.xxx.

### 3.5.2 Configuration example for POCKET PC 2003

The following example describes the configuration for a WLAN ad hoc connection between a Toshiba e800 with integrated WLAN and a CANbox<sup>®</sup> with default settings. This configuration may be similar for other PDAs but it could be different in some kind.

- 1) Set the PDA switch for wireless communication to **ON**.
- 2) The **Wireless LED** of the PDA should light orange.
- 3) Select the menu **Settings** in the PDA **Start Menu** and switch to the page **Connection**.
- 4) Click the symbol **Connection** and change to the page **Extended** in the following dialog.
- 5) Push the button **Network adapter**.
- 6) On the page **Wireless** click on **New Settings** in the box **Wireless Networks**.
- 7) A dialog with the pages **General** and **Authentication** will appear.
- 8) On the page **General** you type **CANbox** for the **Network Name**, choose **Connection with Company** and activate the check box **This is an Ad Hoc Connection**.
- 9) On the page **Authentication** deactivate the check box **Encryption (WEP activated)**.
- 10) Leave the dialog by using the **OK** button.
- 11) Switch to the page **Network Adapters** and select **IEEE 802.11b WLAN Adapter** at the **Adapters** using the pen.
- 12) Activate the radio button **Specific IP Address** and put in a fitting **IP Address** (for example 192.168.0.200) with **Subnetmask** (255.255.255.0).
- 13) Confirm your inputs with the **OK** button and move back to the **Start Page**.
- 14) Switch on the CANbox<sup>®</sup> and build up a connection using the **CANbox<sup>®</sup>** symbol in the control panel.
- 15) If the connection does not work restart the PDA with a soft reset.


### 3.6 CANbox<sup>®</sup> as Router

Firmware version 3.A and later offers the possibility to use the CANbox<sup>®</sup> as router. In this case, two CANboxes can be connected to each other via LAN/WLAN.

Both CANboxes are configured for reception of all Identifiers or certain Identifiers or exclusively for sending by using a CAN acceptance filter. The optimal parameters for the acceptance filter can be determined by using the tool “*Acceptance Filter Calculator*” which is installed with the CANbox<sup>®</sup> tools. All CAN messages that pass the acceptance filter are sent to the other CANbox<sup>®</sup> via LAN/WLAN where they are passed to the CAN bus. The settings of the router mode are stored in the EEPROM of the CANbox<sup>®</sup>. These settings are read when the CANbox<sup>®</sup> is switched on and the router is activated if necessary. Each CAN interface offers a separate router functionality.

The router mode can be configured by using library functions or with the tool „RouterConfiguration“ which is included in the CANbox<sup>®</sup> software. Therefore, the CANboxes have to be installed in the control panel and a connection is possible.

In the configuration one CANbox<sup>®</sup> has to be set to a TCP/IP server and the other CANbox<sup>®</sup> to a TCP/IP client. The server port has to be identical in both CANboxes and can have a value between 1200 and 65530.



Tool RouterConfig

Select a CANbox<sup>®</sup> and click on “**Read**” to read the current router configuration, the firmware version and the interface state from the device. On devices with firmware older than 3.X the interface parameter must be set before reading.

With a click on “**Write**” the configuration into the CANbox<sup>®</sup> will be stored and activated. If the firmware is older then 3.X a restart of the CANbox<sup>®</sup> is necessary to activate the configuration.

The CAN-bus interface is configured with following parameters:

**Bit rate:**

Fixed bit rates from 10kBit/s to 1000kBit/s can be selected.


**Format:**

Selection of witch CAN identifier format to be routed. 11 bit only, 29 bit only or both (Mixed Mode)

**Bus termination:**

Enable or disable the CAN bus termination resistor in the CANbox<sup>®</sup>.

With a click on “**Edit**” the configuration dialog for the router function will be opened.



Configuration dialog for the router function

**Router active:**

Enable or disable the router function for this CAN interface.

**Router mode:**

Firmware 4.A and newer supports the “enhanced mode”. To use this all CANbox<sup>®</sup> devices must have this firmware. The “enhanced mode” offers higher data security and stability as well as the monitoring of the age of CAN messages.

**We recommend to update all CANbox<sup>®</sup> devices to the latest firmware and to use this router mode. (see 3.2, 3.2.4 to update the firmware)**

In the “compatibility mode” you configure router connection to CANbox<sup>®</sup> devices with old firmware versions.

**CAN receiver:**

you activate the CAN receiver on this bus with “enable”. The values in “CAN code” and “CAN mask” are parameter for the acceptance filter. You can calculate these with the tool “AcceptanceFilterCalculator” (3.8).

To optimize the data transfer through the network (minimize TCP overhead) you can instruct the CANbox<sup>®</sup> to collect CAN messages before sending them over the network. Enter the number of messages to collect in “Messages”. The timeout sets

the time after that a single message is sent over the network. You need firmware 3.W or later to enable this feature.

### Network:

You have to select the network interface (LAN or WLAN) for this connection. To establish a connection between two CANbox<sup>®</sup> devices you must configure one device as “**Server**” (waits for incoming connection) and the other device as “**Client**” (connects active with server). Configure the same “**Port**” on the client and the server. You must tell the client the **Server IP address**.

### Enhanced mode:

If you enable the check of message age and enter the “message life time” the CANbox<sup>®</sup> monitors the time from receiving a message on the CAN bus to send the message on the CAN bus of the other CANbox<sup>®</sup>. If this overruns the life time this message is not sent on the destination CAN bus.

## 3.6.1 Configuration examples

### 3.6.1.1 Example 1

All CAN messages from CANbox<sup>®</sup> A interface 1 should be routed to CANbox<sup>®</sup> B interface 1 via WLAN. Only Identifier 0x1000 to 0x100F are to be routed from CANbox<sup>®</sup> B to CANbox<sup>®</sup> A.

CANbox<sup>®</sup> A is configured as server, CANbox<sup>®</sup> B as client. Both CANbox<sup>®</sup>es have firmware 4.A.

The interface parameters (bit rate, termination resistor) must be configured according to the associated CAN bus and the format on both CANbox<sup>®</sup>es must be set to the same value.

	CANbox <sup>®</sup> A interface 1	CANbox <sup>®</sup> B interface 1
Router active	Yes	
Router mode	Enhanced	
Receiver enabled	Yes	
CAN code	0	0000100F
CAN mask	0	1FFFFFF0
Collect messages	No	
Network interface	WLAN	
Type	Server	Client
Server address	N/A	WLAN IP address of CANbox <sup>®</sup> A
Port	1200	
Check message age	No	

### 3.6.1.2 Example 2

CAN messages with identifier 0x2000 to 0x3FFF should be routed from CANbox<sup>®</sup> A interface 2 to CANbox<sup>®</sup> B interface 2 via LAN. No message is to be routed from CANbox<sup>®</sup> B to CANbox<sup>®</sup> A.


CANbox<sup>®</sup> A is configured as client, CANbox<sup>®</sup> B as server. One CANbox<sup>®</sup> has **firmware 4.A**, the other has a **older firmware**.

The interface parameters (bit rate, termination resistor) must be configured according to the associated CAN bus and the format on both CANbox<sup>®</sup>es must be set to the same value.

	CANbox <sup>®</sup> A interface 2	CANbox <sup>®</sup> B interface 2
Router active	Yes	
Router mode	Compatibility	
Receiver enabled	Yes	No
CAN code	00003FFF	N/A
CAN mask	1FFFE000	N/A
Collect messages	No	N/A
Network interface	LAN	
Type	Client	Server
Server address	LAN IP address of CANbox <sup>®</sup> B	N/A
Port	1201	
Check message age	N/A	

### 3.7 Enhanced Router (Forwarder)

The forwarder allows to define up to 10 router connections in one CANbox<sup>®</sup>. This mode is available from firmware version 3.M. Any combination of server, client, CAN interface 1 and CAN interface 2 can be configured.



Tool Forwarderconfig

With checked “Auto read on select” the configuration is read out of the selected CANbox<sup>®</sup>. On a device with firmware older then 3.X the interface parameter Bit rate, Format and Bus termination must be set before reading.

The configuration is the same as described in router configuration (3.6). The selection of the CAN interface is added.

#### 3.7.1 Configuration examples

The examples from router configuration are also valid for forwarder configuration. Select in the forwarder any connection to store the configuration. Additional the CAN interface in the connection configuration must be selected.

##### 3.7.1.1 Example 1

All CAN messages from CANbox<sup>®</sup> A interface 1 should be routed via WLAN to three other CANbox<sup>®</sup>es (B – D) and via LAN to two other CANbox<sup>®</sup>es (E, F). These five CANbox<sup>®</sup> have to route only Identifier 0x11000 to 0x11003. On CANbox<sup>®</sup> B and C is interface 1 connected, on CANbox<sup>®</sup> D – F is interface 2 connected.

**CANbox<sup>®</sup> A:**

The interface parameters (bit rate, termination resistor) must be configured according to the associated CAN bus and the format on both CANbox<sup>®</sup>es must be set to the same value.

	Conn. 1	Conn. 2	Conn. 3	Conn. 4	Conn. 5
CAN bus	Interface 1				
Forwarder active	Yes				
Forwarder Mode	Enhanced				
Receiver enabled	Yes				
CAN code	0				
CAN mask	0				
Collect messages	No				
Network interface	WLAN			LAN	
Type	Server				
Server address	N/A				
<b>Port</b>	<b>1200</b>	<b>1201</b>	<b>1202</b>	<b>1203</b>	<b>1204</b>
Check message age	No				

**CANbox<sup>®</sup> B – F:**

Select any connection to store the configuration.


The interface parameters (bit rate, termination resistor) must be configured according to the associated CAN bus and the format on both CANbox<sup>®</sup>es must be set to the same value.

CANbox <sup>®</sup>	B	C	D	E	F
CAN bus	Interface 1	Interface 1	Interface 2	Interface 2	Interface 2
Forwarder active	Yes				
Forwarder Mode	Enhanced				
Receiver enabled	Yes				
CAN code	00011003				
CAN mask	1FFFFFFC				
Collect messages	No				
Network interface	WLAN			LAN	
Type	Client				
Server address	WLAN IP address of CANbox <sup>®</sup> A			LAN IP address of CANbox <sup>®</sup> A	
<b>Port</b>	<b>1200</b>	<b>1201</b>	<b>1202</b>	<b>1203</b>	<b>1204</b>
Check message age	No				


**3.8 Acceptance Filter calculator**

With this tool the „CAN code“ and „CAN mask“ values for the acceptance filter of the CANbox<sup>®</sup> can be calculated.






A single identifier can be added



or a range of identifiers.



The “CAN code” and “CAN mask” values are calculate immediately after adding or removing an identifier (range).

The “CAN mask” represents a bit mask of valid bits in the “CAN code”. This means: a CAN message will be received or routed if

$$\text{Identifier \& "CAN mask"} == \text{"CAN code"} \& \text{"CAN mask"}$$

The handicap of this filter is following:


To filter identifier 0x100 and 0x200 the bits 8 and 9 of the mask are set to invalid. This causes that the identifier 0x300 is also filtered.

### 3.9 Automatic recovery on heavy CAN bus in router mode

Firmware 3.W or later is required to use this tool.

The CAN controller of the CANbox® has an internal counter for occurrences of errors on the CAN bus. This counter is incremented on errors and decremented on correctly transmitted or received frames. If the counter has reached a limit of 96 the controller goes to „error passive“ state (Bus heavy) and becomes receiver. In this state the controller will transmit no more frames and recovers only on receiving frames. If the counter reaches 256, the controller goes offline (Bus off). In this state doesn't reconnect to the CAN bus.

With the tool “CANboxConfig” you can define a level and a recurrence interval to reinitialize the CAN controller of each interface.



Tool CanboxConfig

First the CANbox® to be configure must be selected. With “Read” the current configuration can be readed.

In the field “Initialize on” the trigger level for the automatic initialization is to be selected.

In the field “Repeat after” the time in ms at the earliest repetition of the initialization .

With “Write” the configuration will be stored to the selected CANbox®.

## 4 CANbox<sup>®</sup> library

The library offers all functions which are necessary for a CAN communication. All functions give an error code as return value. A function returns CB\_ERROR\_OK, if it has been executed successfully. The CANbox<sup>®</sup> library allows hardware configuration and initialization. Furthermore, the library provides functions for reception and transmission of CAN Identifiers. The library is available for Win32 as well as for POCKET PC 2003 operating systems.

### 4.1 Structures and Definitions

#### 4.1.1 CANBOX\_VERSION\_INFO

Structure for version information.

##### 4.1.1.1 Parameter

USHORT	usBuild:	Build number
UCHAR	ucMinor:	Minor version number
UCHAR	ucMajor:	Major version number
UCHAR	ucDay:	Day of build
UCHAR	ucMonth:	Month of build
USHORT	usYear:	Year of build

#### 4.1.2 CANBOX\_TIME\_STAMP

Structure with 64 bits time stamp.

##### 4.1.2.1 Parameter

ULONG	ulTimeLo:	Low-Dword of the time stamp
ULONG	ulTimeHi:	High-Dword of the time stamp

#### 4.1.3 CANBOX\_SCAN\_INFO

Structure for device information of an installed CANbox.

##### 4.1.3.1 Elements

USHORT	usDeviceId:	ID of the CANbox device
USHORT	usConnection:	Type of connection
ULONG	ulTimeout:	Timeout value

#### 4.1.4 CANBOX\_DEVICE\_INFO

Structure for device information of a connected CANbox.

##### 4.1.4.1 Parameter

USHORT	usType:	Type of the CANbox
USHORT	usVariant:	Variant of the CANbox
ULONG	ulSerial:	Serial number of the CANbox
CANBOX_VERSION_INFO	sDriverCan:	Version of the CAN driver
CANBOX_VERSION_INFO	sDriverLan:	Version of the LAN driver
CANBOX_VERSION_INFO	sDriverWlan:	Version of the WLAN driver

#### 4.1.5 CANBOX\_RESET\_EX

Structure to be used for the extended reset function.

##### 4.1.5.1 Parameter

USHORT	usRouterRestart:	Restart of the router after reset
--------	------------------	-----------------------------------

## 4.1.6 CANBOX\_INTERFACE

Structure for interface configuration with declaration of the bit rate.

### 4.1.6.1 Parameter

ULONG	ulBufferSizeMax:	Maximum count of messages stored by the CANbox <sup>®</sup> (0-150.000; 0: available maximum).
USHORT	usIndex:	Index of the interface (1, 2 when using the library or 0, 1 when using the socket interface)
USHORT	usBitRate:	Bit rate
USHORT	usShutOff:	Switching on / off of the CAN bus termination resistance
USHORT	usFormat:	CAN specification (11 bit / 29 bit Identifier)

### 4.1.6.2 Bit rates

CB_BITRATE_0010_KBIT:	10 kBit/s
CB_BITRATE_0020_KBIT:	20 kBit/s
CB_BITRATE_0050_KBIT:	50 kBit/s
CB_BITRATE_0080_KBIT:	80 kBit/s
CB_BITRATE_0083_3_KBIT:	83.3 kBit/s
CB_BITRATE_0100_KBIT:	100 kBit/s
CB_BITRATE_0125_KBIT:	125 kBit/s
CB_BITRATE_0250_KBIT:	250 kBit/s
CB_BITRATE_0500_KBIT:	500 kBit/s
CB_BITRATE_0666_KBIT:	666 kBit/s
CB_BITRATE_0800_KBIT:	800 kBit/s
CB_BITRATE_1000_KBIT:	1 MBit/s

### 4.1.6.3 CAN bus termination resistor

CB_NO_SHUT_OFF:	Off
CB_SHUT_OFF:	On

### 4.1.6.4 Format

CB_FORMAT_MIXED:	11 bit and 29 bit Identifier
CB_FORMAT_11_BIT:	11 bit Identifier
CB_FORMAT_29_BIT:	29 bit Identifier
CB_FORMAT_STD:	Standard mode
CB_FORMAT_BUFFER:	Buffer mode: Each Identifier respectively acceptance filter has a configurable buffer size to be set by usBufferSize.

## 4.1.7 CANBOX\_INTERFACE\_EX

Extended structure for interface configuration with direct declaration of the bit timing parameters.

### 4.1.7.1 Parameter

ULONG	ulBufferSizeMax:	Maximum count of messages stored by the CANbox <sup>®</sup> (0-150.000; 0: available maximum).
USHORT	usIndex:	Index of the interface (1, 2 when using the library or 0, 1 when using the socket interface)
USHORT	usTq:	Time quantum in nanoseconds
USHORT	usTseg1:	Time before the nominal scan time
USHORT	usTseg2:	Time after the nominal scan time
USHORT	usTsjw:	Synchronization jump width
USHORT	usSpB:	Number of samples per bit
USHORT	usShutOff:	Switching on / off of the CAN bus termination resistance
USHORT	usFormat:	CAN specification (11 bit / 29 bit Identifier)

### 4.1.7.2 CAN bus termination resistance

CB_NO_SHUT_OFF:	Off
CB_SHUT_OFF:	On

### 4.1.7.3 Format

CB_FORMAT_MIXED:	11 bit and 29 bit Identifier
CB_FORMAT_11_BIT:	11 bit Identifier
CB_FORMAT_29_BIT:	29 bit Identifier
CB_FORMAT_STD:	Standard mode
CB_FORMAT_BUFFER:	Buffer mode: Each Identifier respectively acceptance filter has a configurable buffer size to be set by usBufferSize.

## 4.1.8 CANBOX\_INTERFACE\_STATE

Structure for state information of an interface.

### 4.1.8.1 Parameter

CANBOX_TIME_STAMP	sTime:	Time stamp of the last change in bus state
USHORT	usBusState:	Bus state
USHORT	usBusInfo:	Information concerning the bus state
USHORT	usUserState:	User state

### 4.1.8.2 Bus state

CB_BUS_STATE_ON:	CAN interface is taking part in bus communication.
CB_BUS_STATE_HEAVY:	Bus is heavily disturbed.
CB_BUS_STATE_OFF:	CAN controller does not take part in bus communication any longer because of too many bus errors.
CB_BUS_STATE_LINE:	Line error signaled from transceiver (only for fault tolerant interfaces).

### 4.1.8.3 Bus info

CB_BUS_INFO_STUFF:	Stuff error (more than 5 equal bits in a message in a row).
CB_BUS_INFO_FORM:	Form error (format error in the message).
CB_BUS_INFO_ACK:	Ack error (sent message has not been acknowledged).
CB_BUS_INFO_BIT_LO:	Bit error 0 (after sending a message, 0 has been read back instead of 1).
CB_BUS_INFO_BIT_HI:	Bit error 1 (after sending a message, 1 has been read back instead of 0).
CB_BUS_INFO_CRC:	CRC error (bad check sum).

### 4.1.8.4 User state

CB_USER_STATE_OFF:	Interface has not been configured yet.
CB_USER_STATE_STARTED:	Interface has been configured and started.
CB_USER_STATE_STOPPED:	Interface has been configured and stopped.

## 4.1.9 CANBOX\_INTERFACE\_INFO

### 4.1.9.1 Parameter

CANBOX_INTERFACE_STATE	sState:	Bus state information
ULONG	ulBufferSizeMax	See CANBOX_INTERFACE (0)
USHORT	usValid:	0 == only sState supported by firmware (3.W or older)
USHORT	usIndex:	See CANBOX_INTERFACE (0)
USHORT	usBitRate:	See CANBOX_INTERFACE (0)
USHORT	usShutOff	See CANBOX_INTERFACE (0)
USHORT	usFormat	See CANBOX_INTERFACE (0)
USHORT	usTq	See CANBOX_INTERFACE (0)
USHORT	usTseg1	See CANBOX_INTERFACE (0)
USHORT	usTseg2	See CANBOX_INTERFACE (0)
USHORT	usTsjw	See CANBOX_INTERFACE (0)
USHORT	usSpB	See CANBOX_INTERFACE (0)

## 4.1.10 CANBOX\_INTERFACE\_READ

Structure for reception data of an interface.

### 4.1.10.1 Parameter

CANBOX_TIME_STAMP	sTime:	Time stamp
ULONG	ulId:	CAN Id of the Identifier
ULONG	ulDataSize:	Number of valid data bytes
UCHAR	ucData[8] (ucData0 to ucData7 at VB):	Data bytes of the Identifier

## 4.1.11 CANBOX\_INTERFACE\_WRITE

Structure for sending data of an interface.

### 4.1.11.1 Parameter

CANBOX_TIME_STAMP	sTime:	Time stamp
CANBOX_HANDLE	hIdentifier:	Handle of the Identifier to be sent
ULONG	ulDataSize:	Number of valid data bytes for sending
UCHAR	ucData[8] (ucData0 to ucData7 at VB):	Data bytes of the Identifier



### 4.1.12 CANBOX\_IDENTIFIER

Structure for identifier configuration.

#### 4.1.12.1 Parameter

ULONG	uId:	Id of the Identifier. In mixed mode, the most significant bit can be set for marking 29 bit Identifiers. This bit is then set in the received data.
USHORT	usType:	Type of the Identifier.
USHORT	usFlags:	Options for the Identifier.
USHORT	usTimeout:	Maximum time in $\mu$ s of waiting for the answer for active receivers.
USHORT	usReserved:	Reserved parameter which has to be filled with the zero based index of the interface when using the socket interface.
USHORT	usBufferSize:	Buffer size. This parameter has no effect when using the socket interface.

#### 4.1.12.2 Types

CB_DEVICE_RECEIVER:	Standard receiver (passive)
CB_DEVICE_RECEIVER_ACTIVE:	Active receiver
CB_DEVICE_TRANSMITTER:	Standard sender (active)
CB_DEVICE_TRANSMITTER_PASSIVE:	Passive sender (not available in mixed mode)

#### 4.1.12.3 Options

CB_FLAG_ACKNOWLEDGE:	Creation of acknowledgements for senders
CB_FLAG_EXCLUSIVE:	Exclusive buffer reservation on the CAN controller (not available in mixed mode)
CB_FLAG_FORMAT_29_BIT:	Acceptance filter for 29 bit Identifiers in mixed mode

### 4.1.13 CANBOX\_ACCEPTANCE\_FILTER

Structure for configuration of the acceptance filter. An acceptance filter allows the reception of a group of CAN Identifiers. All Identifiers are received which fulfill the criterion  $(ID \& Filter.ulMask) == (Filter.uId \& Filter.ulMask)$ . If the Identifiers 0xA (10dec) and 0xB (11dec) are to be received, the acceptance filter has to be set to  $uId=0x0000000A$  and  $ulMask=0x0000000E$ .

#### 4.1.13.1 Parameter

ULONG	uId:	Identifier of the filter. In mixed mode, the most significant bit can be set for marking 29 bit Identifiers. This bit is then set in the received data.
ULONG	ulMask:	Bit mask of the filter.
USHORT	usType:	Type of the filter.
USHORT	usFlags:	Options for the filter.
USHORT	usReserved:	Reserved parameter which has to be filled with the zero based index of the interface when using the socket interface.
USHORT	usBufferSize:	Buffer size. This parameter has no effect when using the socket interface.

#### 4.1.13.2 Types

CB\_FILTER\_DATA: Acceptance filter for data frames.  
 CB\_FILTER\_REMOTE: Acceptance filter for remote frames (not available in mixed mode).

#### 4.1.13.3 Options

CB\_FLAG\_FORMAT\_29\_BIT: Acceptance filter for 29 bit Identifiers in mixed mode.

### 4.1.14 CANBOX\_ROUTER

Structure for router configuration. A router allows a connection between two CANboxes via LAN or WLAN respectively. A group of Identifiers (see acceptance filter) can be received and sent over LAN/WLAN to the other CANbox. This CANbox sends the data which has been received via LAN/WLAN to the CAN bus.

#### 4.1.14.1 Parameter

USHORT	usIndex:	Reserved parameter which has to be set to the value 1.
USHORT	usType:	Type of the router.
USHORT	usMode:	Mode of the router.
USHORT	usFlags:	Options for the router.
ULONG	ulServerIp:	IP address of the server CANbox.
USHORT	usServerPort:	Port address of the server CANbox.
USHORT	usReserved:	Reserved parameter which has to be filled with the zero based index of the interface when using the socket interface.
ULONG	ulCanId:	Identifier of the CAN acceptance filter (0xFFFFFFFF: no data will be received on the local CAN bus).
ULONG	ulCanMask:	Bit mask of the CAN acceptance filter.

#### 4.1.14.2 Types

CB\_ROUTER\_LAN\_SERVER: Connection via LAN as TCP/IP server.  
 CB\_ROUTER\_LAN\_CLIENT: Connection via LAN as TCP/IP client.  
 CB\_ROUTER\_WLAN\_SERVER: Connection via WLAN as TCP/IP server.  
 :  
 CB\_ROUTER\_WLAN\_CLIENT: Connection via WLAN as TCP/IP client.

#### 4.1.14.3 Mode

CB\_ROUTER\_INACTIVE: Router is not activated.  
 CB\_ROUTER\_ACTIVE: Router is activated.

#### 4.1.14.4 Options

CB\_FLAG\_FORMAT\_29\_BIT: Acceptance filter for 29 bit Identifiers in mixed mode.

### 4.1.15 CANBOX\_ROUTER\_EX

Structure for router configuration with latency consideration. A router allows a connection between two CANboxes via LAN or WLAN respectively. A group of Identifiers (see acceptance filter) can be received and sent over LAN/WLAN to the other CANbox. This CANbox sends the data which has been received via LAN/WLAN to the CAN bus.

#### 4.1.15.1 Parameter

USHORT	usIndex:	normal mode: Reserved parameter which has to be set to the value 1 enhanced mode: Zero based index of the requested data set (0..9)
USHORT	usType:	Type of the router.
USHORT	usMode:	Mode of the router.
USHORT	usFlags:	Options for the router.
ULONG	ulServerIp:	IP address of the server CANbox.
USHORT	usServerPort:	Port address of the server CANbox.
USHORT	usReserved:	Reserved parameter which has to be filled with the zero based index of the interface when using the socket interface.
ULONG	ulCanId:	Identifier of the CAN acceptance filter (0xFFFFFFFF: no data will be received on the local CAN bus).
ULONG	ulCanMask:	Bit mask of the CAN acceptance filter.
ULONG	ulLatency:	Maximum latency time for sending the messages to the CAN bus. (5-10.000 ms)
USHORT	usCollect	number of messages to collect before send via TCP
USHORT	usCollectTimeo ut	max. time [ms] to wait for more messages until send a message via TCP

#### 4.1.15.2 Types

CB_ROUTER_LAN_SERVER:	Connection via LAN as TCP/IP server
CB_ROUTER_LAN_CLIENT:	Connection via LAN as TCP/IP client
CB_ROUTER_WLAN_SERVER:	Connection via WLAN as TCP/IP server
CB_ROUTER_WLAN_CLIENT:	Connection via WLAN as TCP/IP client
CB_FORWARDER_LAN_SERVER:	Connection via LAN as TCP/IP server (enhanced mode)
CB_FORWARDER_LAN_CLIENT:	Connection via LAN as TCP/IP client (enhanced mode)
CB_FORWARDER_WLAN_SERVER:	Connection via WLAN as TCP/IP server (enhanced mode)
CB_FORWARDER_WLAN_CLIENT:	Connection via WLAN as TCP/IP client (enhanced mode)

#### 4.1.15.3 Mode

CB_ROUTER_INACTIVE:	Router is not activated.
CB_ROUTER_ACTIVE:	Router is activated.

#### 4.1.15.4 Options

CB_FLAG_ROUTER_EXTENDED:	Activates enhanced mode
CB_FLAG_FORMAT_29_BIT:	Acceptance filter for 29 bit Identifiers in mixed mode
CB_FLAG_FORMAT_11_BIT:	Acceptance filter for 11 bit Identifiers in mixed mode
CB_FLAG_FORMAT_MIXED:	Open both 11 and 29 bit acceptance filter

### 4.1.16 CANBOX\_LAN\_CONFIG

Structure for setting respectively getting the LAN settings of the CANbox<sup>®</sup>.

#### 4.1.16.1 Parameter

ULONG	ullp:	IP address of the CANbox <sup>®</sup> .
ULONG	ulSubnetmask:	Subnetmask of the CANbox <sup>®</sup> .

### 4.1.17 CANBOX\_WLAN\_CONFIG

Structure for setting respectively getting the WLAN settings of the CANbox<sup>®</sup>.

#### 4.1.17.1 Parameter

ULONG	ullp:	IP address of the CANbox <sup>®</sup> .
ULONG	ulSubnetmask:	Subnetmask of the CANbox <sup>®</sup> .
UCHAR[34]	ucSSID:	Network name with up to 34 characters.
USHORT	usMode:	Type of connection (AdHoc, Access Point).
USHORT	usOwnChannel:	WLAN channel from 1 to 14.
USHORT	usAuthentication:	Authentication <i>Open System</i> or <i>Shared Key</i> .
USHORT	usEncryption:	Encryption <i>Switched Off</i> or <i>WEP</i> .
USHORT	usKeyId:	Zero based index of the used key.
UCHAR[16]	ucKey0:	Key 0 (usKeyId=0).
UCHAR[16]	ucKey1:	Key 1 (usKeyId=1).
UCHAR[16]	ucKey2:	Key 2 (usKeyId=2).
UCHAR[16]	ucKey3:	Key 3 (usKeyId=3).

#### 4.1.17.2 Mode

CB_WLAN_ACCESS_POINT	Connection via access point as TCP/IP server.
CB_WLAN_AD_HOC	AdHoc connection.

#### 4.1.17.3 Authentication

CB_WLAN_OPEN_SYSTEM	Open System.
CB_WLAN_SHARED_KEY	Shared Key.

#### 4.1.17.4 Encryption

CB_WLAN_ENCRYPTION_OFF	Switched off.
CB_WLAN_ENCRYPTION_WEP	WEP.

#### 4.1.18 CANBOX\_IDENTIFIER\_DATA

Structure with CAN Identifier data.

##### 4.1.18.1 Parameter

CANBOX_TIME_STAMP	sTime:	Time stamp at time of reception.
ULONG	uId:	CAN Id of the Identifier. In mixed mode the most significant bit is set for 29 bit Identifiers if it was set at opening the Identifier.
ULONG	ulDataSize:	Number of valid data bytes
UCHAR	ucData[8] (ucData0 to ucData7 at VB):	Data bytes

#### 4.1.19 CANBOX\_UNIVERSAL\_SENDER\_DATA

Structure for sending a CAN message by using a general sending object. With a general sending object, any Identifier can be sent by declaration of the Id.

##### 4.1.19.1 Parameter

ULONG	uId:	CAN Identifier. In mixed mode the most significant bit can be used for marking 29 bit Identifiers.
USHORT	usFlags:	Options.
ULONG	ulDataSize:	Number of data to be sent.
UCHAR	ucData[8] (ucData0 to ucData7 at VB):	Data to be sent.

##### 4.1.19.2 Options

CB_FLAG_FORMAT_29_BIT:	Flag for marking a 29 bit Identifier in mixed mode.
------------------------	---

#### 4.1.20 CANBOX\_16

Supporting structure for using the CANbox<sup>®</sup> with Visual Basic.

##### 4.1.20.1 Parameter

UCHAR	ucLoByte:	Lower byte.
UCHAR	ucHiByte:	Higher byte.

## 4.1.21 CANBOX\_32

Supporting structure for using the CANbox<sup>®</sup> with Visual Basic.

### 4.1.21.1 Parameter

UCHAR	ucLoByte:	Lowest byte.
UCHAR	ucByte1:	Higher byte of the lower word.
UCHAR	ucByte2:	Lower byte of the upper word.
UCHAR	ucHiByte:	Highest byte.

## 4.2 Error codes

CB\_ERROR\_OK: No error

### 4.2.1 General error messages of the CANbox<sup>®</sup>

CB\_ERROR\_SIZE\_INPUT: Size of input data invalid  
CB\_ERROR\_SIZE\_OUTPUT: Size of output data invalid  
CB\_ERROR\_DATA: Error in given data  
CB\_ERROR\_STATE: Invalid state  
CB\_ERROR\_MEMORY: Error at accessing RAM memory  
CB\_ERROR\_FLASH: Error at accessing the FLASH memory  
CB\_ERROR\_EEPROM: Error at EEPROM access  
CB\_ERROR\_NOT\_SUPPORTED: Function not supported (check library and firmware version)

#### 1.1.1. Error messages concerning initialization

CB\_ERROR\_CAN\_INIT: Error at initializing the CAN firmware  
CB\_ERROR\_HARDWARE\_INIT: Error at initializing the CPU  
CB\_ERROR\_MEMORY\_INIT: Error at memory allocation

#### 1.1.2. Error messages concerning release

CB\_ERROR\_CAN\_EXIT: Error at releasing the CAN mdd

#### 1.1.3. Error messages concerning CAN interfaces

CB\_ERROR\_INTERFACE\_INDEX: Invalid interface index  
CB\_ERROR\_INTERFACE\_STATE: Invalid interface state (for the desired operation)  
CB\_ERROR\_INTERFACE\_OPEN: Error at opening the interface  
CB\_ERROR\_INTERFACE\_OPEN\_BITRATE: The interface has already been opened with a different bit rate.  
CB\_ERROR\_INTERFACE\_OPEN\_FORMAT: The interface has already been opened with a different message format (11bits/29 bits)  
CB\_ERROR\_INTERFACE\_BITRATE: Unsupported bit rate  
CB\_ERROR\_INTERFACE\_SHUT\_OFF: Invalid value for the terminating resistance  
CB\_ERROR\_INTERFACE\_FORMAT: Invalid value for the CAN format.  
CB\_ERROR\_INTERFACE\_INIT: Error at initializing a CAN interface  
CB\_ERROR\_INTERFACE\_CONTROL: Error at controlling a CAN interface  
CB\_ERROR\_INTERFACE\_EXIT: Error at clearing a CAN interface

#### 1.1.4. Error messages concerning CAN Identifier

CB\_ERROR\_IDENTIFIER\_INIT: Error at initializing a CAN Identifier  
CB\_ERROR\_IDENTIFIER\_TYPE: Invalid Identifier type  
CB\_ERROR\_IDENTIFIER\_EXCLUSIVE: Invalid value for exclusive flag  
CB\_ERROR\_IDENTIFIER\_READ: Error at reading data

CB\_ERROR\_IDENTIFIER\_WRITE: Error at writing data

### 1.1.5. Error messages concerning acceptance filters

CB\_ERROR\_FILTER\_INIT: Error at initializing an acceptance filter

CB\_ERROR\_FILTER\_TYPE: Invalid filter type

CB\_ERROR\_FILTER\_SET: Error at setting the filter configuration

### 1.1.6. Error messages concerning universal senders

CB\_ERROR\_SENDER\_INIT: Error at initializing an universal sender

CB\_ERROR\_SENDER\_WRITE: Error at writing data of an universal sender

### 1.1.7. General error messages of the library

CB\_ERROR\_NO\_INIT: Missing initialization.

CB\_ERROR\_PARAMETER: Wrong parameter.

CB\_ERROR\_HANDLE: Invalid handle.

CB\_ERROR\_HANDLE\_TYPE: Invalid handle type.

### 1.1.8. Error messages of the library concerning the connection to the CANbox<sup>®</sup>

CB\_ERROR\_CONNECTION\_INIT: Connection could not be established.

CB\_ERROR\_CONNECTION\_IN\_USE: CANbox<sup>®</sup> is already connected to another application.

CB\_ERROR\_CONNECTION\_TIMEOUT: Timeout while accessing the CANbox<sup>®</sup>.

CB\_ERROR\_CONNECTION\_RECEIVE: Error at data reception from the CANbox<sup>®</sup>.

CB\_ERROR\_CONNECTION\_SEND: Error at sending data to the CANbox<sup>®</sup>.

CB\_ERROR\_CONNECTION\_EXIT: Connection could not be shut down.

CB\_ERROR\_DEVICE\_NOT\_INSTALLED: The addressed CANbox<sup>®</sup> is not installed in the control panel.



## 4.3 General Functions

### 4.3.1 canbox\_init\_lib

Initialization of the library. This function has to be called once before any other library function. Otherwise all functions return the error CB\_NO\_INIT.

#### 4.3.1.1 Parameter

None.

### 4.3.2 canbox\_get\_driver\_version

Delivers information about the driver versions.

#### 4.3.2.1 Parameter

CANBOX\_VERSION\_INFO\* psInfo:                      Pointer to structure for version information

### 4.3.3 canbox\_get\_error\_message

Retrieves the error message for an error code.

#### 4.3.3.1 Parameter

CANBOX_ERROR	Error:	Error code.
USHORT*	pusSize:	Size of the character array.
char*	szMessage:	Character array for message text.

### 4.3.4 canbox\_exit\_lib

Free allocated resources. This function has to be called at the end.

#### 4.3.4.1 Parameter

None

## 4.4 Device Functions

### 4.4.1 canbox\_scan\_devices

Gives a list of the installed CANboxes.

#### 4.4.1.1 Parameter

USHORT*	pusCount:	Maximum number of device information structures. The driver sets the number to the used count.
CANBOX_SCAN_INFO*	pasInfo:	Pointer to array of info structures for device information.

### 4.4.2 canbox\_get\_device\_parameter

Gives communication parameter (IP address or serial interface) from registry.

#### 4.4.2.1 Parameter

DWORD	dwId:	Id of CANbox to query
CHAR*	szText:	Pointer to array of char for parameter information.
DWORD	dwSize:	Size of buffer szText

### 4.4.3 canbox\_open\_device

Opens the device with the given Id. The connection to the device is built up.

#### 4.4.3.1 Parameter

USHORT	usId:	Id of the device to be opened.
CANBOX_HANDLE*	phDevice:	Pointer to handle for the device.

### 4.4.4 canbox\_reset\_device

Resets the device. All open Identifiers and interfaces of the device are closed and the bus communication of the interfaces is stopped. The receive buffers are cleared. The time stamp is reset to zero. The connection maintains alive and the device handle keeps valid. Active Routers are restarted after reset.

#### 4.4.4.1 Parameter

CANBOX_HANDLE	hDevice:	Received handle of the device after calling canbox_open_device.
---------------	----------	---

#### 4.4.5 canbox\_reset\_device\_ex

Resets the device. All open Identifiers and interfaces of the device are closed and the bus communication of the interfaces is stopped. The receive buffers are cleared. The time stamp is reset to zero. The connection maintains alive and the device handle keeps valid. Additionally it is possible to determine, if active Routers are to be restarted after reset.

##### 4.4.5.1 Parameter

CANBOX_HANDLE	hDevice:	Received handle of the device after calling canbox_open_device.
CANBOX_RESET_EX	sResetEx:	Structure for configuring the reset behavior.

#### 4.4.6 canbox\_get\_device\_info

Gives information about the device.

##### 4.4.6.1 Parameter

CANBOX_HANDLE	hDevice:	Received handle of the device after calling canbox_open_device.
CANBOX_DEVICE_INFO*	psInfo:	Pointer to an info structure for device information.

#### 4.4.7 canbox\_reset\_time\_stamp

Resets the time stamp to zero. The time stamp has a resolution of 0.1 micro seconds.

##### 4.4.7.1 Parameter

CANBOX_HANDLE	hDevice:	Received handle of the device after calling canbox_open_device.
---------------	----------	---

#### 4.4.8 canbox\_set\_time\_stamp

Sets the time stamp to the given value. The time stamp has a resolution of 0.1 micro seconds.

##### 4.4.8.1 Parameter

CANBOX_HANDLE	hDevice:	Received handle of the device after calling canbox_open_device.
CANBOX_TIME_STAMP	sTime:	Structure with new time stamp value.

#### 4.4.9 canbox\_set\_time\_stamp\_by\_ref

Sets the time stamp to the given value. The time stamp has a resolution of 0.1 micro seconds.

##### 4.4.9.1 Parameter

CANBOX_HANDLE	hDevice:	Received handle of the device after calling canbox_open_device.
CANBOX_TIME_STAMP*	psTime:	Pointer to structure with new time stamp value.

#### 4.4.10 canbox\_close\_device

Stops the communication with the device.

##### 4.4.10.1 Parameter

CANBOX_HANDLE	hDevice:	Received handle of the device after calling canbox_open_device.
---------------	----------	---

### 4.5 Interface Functions

#### 4.5.1 canbox\_get\_interface\_info

Supplies the state of the CAN interface with parameter info. If the CANbox<sup>®</sup> has firmware older then 3.X only the sState field is filled and usValid field is set to 0.

##### 4.5.1.1 Parameter

CANBOX_HANDLE	hDevice:	Received handle of the device after calling canbox_open_device.
USHORT	usIndex:	Zero based Index of CAN interface
CANBOX_INTERFACE_INFO*	psInfo:	Pointer to structure for state and parameter information.

#### 4.5.2 canbox\_open\_interface

Opens a CAN interface and configures it with the given parameters. The bit rate is given and the bit timing parameters are calculated from the bit rate value.

##### 4.5.2.1 Parameter

CANBOX_HANDLE	hDevice:	Received handle of the device after calling canbox_open_device.
CANBOX_INTERFACE	sInterface:	Structure for interface configuration.
CANBOX_HANDLE*	phInterface:	Pointer to handle for the handle of the interface.

#### 4.5.3 canbox\_open\_interface\_by\_ref

Opens a CAN interface and configures it with the given parameters. The bit rate is given and the bit timing parameters are calculated from the bit rate value.

##### 4.5.3.1 Parameter

CANBOX_HANDLE	hDevice:	Received handle of the device after calling canbox_open_device.
CANBOX_INTERFACE*	psInterface:	Pointer to structure for interface configuration.
CANBOX_HANDLE*	phInterface:	Pointer to handle for the handle of the interface.

#### 4.5.4 canbox\_open\_interface\_ex

Opens a CAN interface and configures it with the given parameters. Bit timing parameters are given directly.

##### 4.5.4.1 Parameter

CANBOX_HANDLE	hDevice:	Received handle of the device after calling canbox_open_device.
CANBOX_INTERFACE_EX	sInterface:	Structure for interface configuration.
CANBOX_HANDLE*	phInterface:	Pointer to handle for the handle of the interface.

#### 4.5.5 canbox\_open\_interface\_ex\_by\_ref

Opens a CAN interface and configures it with the given parameters. Bit timing parameters are given directly.

##### 4.5.5.1 Parameter

CANBOX_HANDLE	hDevice:	Received handle of the device after calling canbox_open_device.
CANBOX_INTERFACE_EX*	psInterface:	Pointer to structure for interface configuration.
CANBOX_HANDLE*	phInterface:	Pointer to handle for the handle of the interface.

#### 4.5.6 canbox\_get\_interface\_state

Supplies the state of the CAN interface.

##### 4.5.6.1 Parameter

CANBOX_HANDLE	hInterface:	Received handle of the interface after calling canbox_open_interface respectively canbox_open_interface_ex.
CANBOX_INTERFACE_STATE*	psState:	Pointer to structure for state information.

#### 4.5.7 canbox\_get\_last\_interface\_time

Delivers the last time stamp value where a message has been received.

##### 4.5.7.1 Parameter

CANBOX_HANDLE	hInterface:	Received handle of the interface after calling canbox_open_interface respectively canbox_open_interface_ex.
CANBOX_TIME_STAMP*	psTime:	Pointer to a structure for time stamp value.

## 4.5.8 canbox\_clear\_interface

Clears the data buffer of an interface.

### 4.5.8.1 Parameter

CANBOX_HANDLE	hInterface:	Received handle of the interface after calling canbox_open_interface respectively canbox_open_interface_ex.
---------------	-------------	---

## 4.5.9 canbox\_start\_interface

Starts a stopped CAN interface.

### 4.5.9.1 Parameter

CANBOX_HANDLE	hInterface:	Received handle of the interface after calling canbox_open_interface respectively canbox_open_interface_ex.
---------------	-------------	---

## 4.5.10 canbox\_read\_interface

Reads a data set (received message) out of the data buffer of the CAN interface.

### 4.5.10.1 Parameter

CANBOX_HANDLE	hInterface:	Received handle of the interface after calling canbox_open_interface respectively canbox_open_interface_ex.
CANBOX_INTERFACE_READ*	psData:	Pointer to structure for data.

## 4.5.11 canbox\_read\_interface\_ex

Reads one or more data sets (received messages) out of the data buffer of the CAN interface.

### 4.5.11.1 Parameter

CANBOX_HANDLE	hInterface:	Received handle of the interface after calling canbox_open_interface respectively canbox_open_interface_ex.
USHORT*	pusCount:	Maximum number of data sets to be delivered.
CANBOX_INTERFACE_READ*	pasData:	Pointer to array of structures for data.

#### 4.5.12 canbox\_write\_interface

Writes the given data of the given identifier to the CAN bus.

##### 4.5.12.1 Parameter

CANBOX_HANDLE	hInterface:	Received handle of the interface after calling canbox_open_interface respectively canbox_open_interface_ex.
CANBOX_INTERFACE_WRITE*	psData:	Pointer to structure array with information about the Identifier and data to be sent.

#### 4.5.13 canbox\_write\_interface\_ex

Writes the given data of the given Identifiers to the CAN bus.

##### 4.5.13.1 Parameter

CANBOX_HANDLE	hInterface:	Received handle of the interface after calling canbox_open_interface respectively canbox_open_interface_ex.
USHORT*	pusCount:	Number of data sets for sending.
CANBOX_INTERFACE_WRITE*	pasData:	Pointer to structure array with information about the Identifiers and their data to be sent.

#### 4.5.14 canbox\_stop\_interface

Stops a running CAN interface. The CAN interface does not take part at the bus communication any longer.

##### 4.5.14.1 Parameter

CANBOX_HANDLE	hInterface:	Received handle of the interface after calling canbox_open_interface respectively canbox_open_interface_ex.
---------------	-------------	---

#### 4.5.15 canbox\_close\_interface

Closes an open CAN interface. The CAN interface does not take part at the bus communication any longer. All Identifier, acceptance filter and universal sender of the interface are also closed.

##### 4.5.15.1 Parameter

CANBOX_HANDLE	hInterface:	Received handle of the interface after calling canbox_open_interface respectively canbox_open_interface_ex.
---------------	-------------	---

## 4.6 Identifier Functions

### 4.6.1 canbox\_open\_identifier

Opens an Identifier and configures it with the given parameters.

#### 4.6.1.1 Parameter

CANBOX_HANDLE	hInterface:	Received handle of the interface after calling canbox_open_interface respectively can_box_open_interface_ex.
CANBOX_IDENTIFIER	sIdentifier:	Structure containing the configuration of the Identifier
CANBOX_HANDLE*	phIdentifier:	Pointer to handle for receiving the handle of the Identifier

### 4.6.2 canbox\_open\_identifier\_by\_ref

Opens an identifier and configures it with the given parameters.

#### 4.6.2.1 Parameter

CANBOX_HANDLE	hInterface:	Received handle of the interface after calling canbox_open_interface respectively can_box_open_interface_ex.
CANBOX_IDENTIFIER*	psIdentifier:	Pointer to a structure containing the configuration of the Identifier
CANBOX_HANDLE*	phIdentifier:	Pointer to handle for receiving the handle of the Identifier

### 4.6.3 canbox\_read\_identifier

Reads a data set (CAN message) of the CAN identifier.

#### 4.6.3.1 Parameter

CANBOX_HANDLE	hIdentifier:	Received handle of the Identifier after calling canbox_open_identifier
CANBOX_IDENTIFIER_DATA*	psData:	Pointer to a structure for the data

### 4.6.4 canbox\_write\_identifier

Writes identifier data to the CAN bus.

#### 4.6.4.1 Parameter

CANBOX_HANDLE	hIdentifier:	Received handle of the Identifier after calling canbox_open_identifier
CANBOX_IDENTIFIER_DATA*	psData:	Pointer to a structure with the data to be sent.



### 4.6.5 canbox\_close\_identifier

Closes an existing CAN identifier.

#### 4.6.5.1 Parameter

CANBOX_HANDLE	hIdentifier:	Received handle of the Identifier after calling canbox_open_identifier
---------------	--------------	--

## 4.7 Acceptance Filter Functions

### 4.7.1 canbox\_open\_acceptance\_filter

Opens an acceptance filter and configures it with the given parameters.

#### 4.7.1.1 Parameter

CANBOX_HANDLE	hInterface:	Received handle of the interface after calling canbox_open_interface respectively can_box_open_interface_ex.
CANBOX_ACCEPTANCE_FILTER	sFilter:	Structure containing the configuration of the filter.
CANBOX_HANDLE*	phIdentifier:	Pointer to handle for receiving the handle of the filter.

### 4.7.2 canbox\_open\_acceptance\_filter\_by\_ref

Opens an acceptance filter and configures it with the given parameters.

#### 4.7.2.1 Parameter

CANBOX_HANDLE	hInterface:	Received handle of the interface after calling canbox_open_interface respectively can_box_open_interface_ex.
CANBOX_ACCEPTANCE_FILTER*	psFilter:	Pointer to a structure containing the configuration of the filter.
CANBOX_HANDLE*	phIdentifier:	Pointer to handle for receiving the handle of the filter.

### 4.7.3 canbox\_read\_acceptance\_filter

Reads data of an acceptance filter.

#### 4.7.3.1 Parameter

CANBOX_HANDLE	hFilter:	Received handle of the filter after calling canbox_open_acceptance_filter.
CANBOX_IDENTIFIER_DATA*	psData:	Pointer to a structure for received data.

#### 4.7.4 canbox\_close\_acceptance\_filter

Closes an existing acceptance filter.

##### 4.7.4.1 Parameter

CANBOX_HANDLE	hFilter:	Received handle of the filter after calling canbox_open_acceptance_filter.
---------------	----------	--

### 4.8 Universal Sender Functions

#### 4.8.1 canbox\_open\_universal\_sender

Opens an universal sender. An universal sender is an object for sending any CAN message by specifying the Id and the data set.

##### 4.8.1.1 Parameter

CANBOX_HANDLE	hInterface:	Received handle of the interface after calling canbox_open_interface respectively can_box_open_interface_ex.
CANBOX_HANDLE*	phSender:	Pointer to handle for receiving the handle of the universal sender

#### 4.8.2 canbox\_write\_universal\_sender

Sends one message by using an universal sender.

##### 4.8.2.1 Parameter

CANBOX_HANDLE	hSender:	Received handle of the universal sender after calling canbox_open_universal_sender.
CANBOX_UNIVERSAL_SENDER_DATA*	psData:	Pointer to the data for sending.

#### 4.8.3 canbox\_write\_universal\_sender\_ex

Sends one or more messages by using a universal sender. If not all messages can be sent directly, those not sent are saved in a software buffer and are sent when the CAN bus is free.

##### 4.8.3.1 Parameter

CANBOX_HANDLE	hSender:	Received handle of the universal sender after calling canbox_open_universal_sender.
USHORT*	pusCount:	Number of data sets to be sent.
CANBOX_UNIVERSAL_SENDER_DATA*	psData:	Pointer to the data for sending.

#### 4.8.4 canbox\_close\_universal\_sender

Closes an existing universal sender.

##### 4.8.4.1 Parameter

CANBOX_HANDLE	hSender:	Received handle of the universal sender after calling canbox_open_universal_sender.
---------------	----------	---

### 4.9 Router Functions

#### 4.9.1 canbox\_read\_router\_config

Gives the current configuration of the interfaces router.

##### 4.9.1.1 Parameter

CANBOX_HANDLE	hInterface:	Received handle of the interface after calling canbox_open_interface respectively can_box_open_interface_ex.
CANBOX_ROUTER*	psRouter:	Pointer to structure for receiving the router parameters.

#### 4.9.2 canbox\_read\_router\_config\_ex

Gives the current configuration of the interfaces router.

##### 4.9.2.1 Parameter

CANBOX_HANDLE	hInterface:	Received handle of the interface after calling canbox_open_interface respectively can_box_open_interface_ex.
CANBOX_ROUTER_EX*	psRouter:	Pointer to structure for receiving the router parameters.

#### 4.9.3 canbox\_write\_router\_config

Configures the router with the given values.

##### 4.9.3.1 Parameter

CANBOX_HANDLE	hInterface:	Received handle of the interface after calling canbox_open_interface respectively can_box_open_interface_ex.
CANBOX_ROUTER	sRouter:	Structure for configuring the router.

#### 4.9.4 canbox\_write\_router\_config\_ex

Configures the router with the given values.

##### 4.9.4.1 Parameter

CANBOX_HANDLE	hInterface:	Received handle of the interface after calling canbox_open_interface respectively can_box_open_interface_ex.
CANBOX_ROUTER_EX	sRouter:	Structure for configuring the router.

### 4.10 Supporting Functions for Visual Basic

As Visual Basic does not allow the correct alignment of some CANbox structures, the structures CANBOX\_16 and CANBOX\_32 have been created. These replace 16 bit respectively 32 bit values in several structures in order to ensure correct alignment. The following functions can be used for conversion from respectively into the structures.

#### 4.10.1 canbox\_convert\_to\_CANbox16

Conversion of a 16 bit value into a CANBOX\_16 structure.

##### 4.10.1.1 Parameter

USHORT	usValue:	16 bit value for conversion
--------	----------	-----------------------------

#### 4.10.2 canbox\_convert\_to\_CANbox16\_by\_ref

Conversion of a 16 bit value into a CANBOX\_16 structure.

##### 4.10.2.1 Parameter

USHORT	usValue:	16 bit value for conversion
CANBOX_16*	psValue:	Pointer to a CANBOX_16 structure

#### 4.10.3 canbox\_convert\_from\_CANbox16

Conversion of a CANBOX\_16 structure to a 16 bit value.

##### 4.10.3.1 Parameter

CANBOX_16*	psValue:	Pointer to a CANBOX_16 structure for conversion
------------	----------	---

#### 4.10.4 canbox\_convert\_to\_CANbox32

Conversion of a 32 bit value into a CANBOX\_32 structure.

##### 4.10.4.1 Parameter

ULONG	ulValue:	32 bit value for conversion
-------	----------	-----------------------------

#### 4.10.5 canbox\_convert\_to\_CANbox32\_by\_ref

Conversion of a 32 bit value into a CANBOX\_32 structure.

##### 4.10.5.1 Parameter

ULONG	ulValue:	32 bit value for conversion
CANBOX_32*	psValue:	Pointer to a CANBOX_32 structure

#### 4.10.6 canbox\_convert\_from\_CANbox32

Conversion of a CANBOX\_32 structure to a 32 bit value.

##### 4.10.6.1 Parameter

CANBOX_32*	psValue:	Pointer to a CANBOX_32 structure for conversion
------------	----------	---

## 5 Socket Interface

The communication with the CANbox<sup>®</sup> can take place by directly using the socket interface instead of using the library. For this the CANbox<sup>®</sup> offers the port 1024 as server port for the LAN as well as the WLAN interface.

Furthermore, the port 1040 can be used as server port for resetting the connection on port 1024. This can be done by building up a connection to port 1040, if the IP addresses of both client ports are identical.

### 5.1. Structures and Definitions

After building up a connection to the CANbox, the communication takes place by using the structures CANBOX\_SOCKET\_IN and CANBOX\_SOCKET\_OUT.

#### 5.1.1 CANBOX\_SOCKET\_IN

Structure for sending data to the CANbox.

##### 5.1.1.1 Parameter

USHORT	usMacro:	0xEE44.
USHORT	usSizeIn:	Number of given bytes + 8.
USHORT	usSizeOut:	Maximum number of expected bytes in answer.
USHORT	usTask:	0x0090.
USHORT	usFunc:	Index of function to be called (see below).
UCHAR	usData[1440]	Data.

#### 5.1.2 CANBOX\_SOCKET\_OUT

Structure for reception of data from the CANbox.

##### 5.1.2.1 Parameter

USHORT	usMacro:	0x0144, if no error occurred.
USHORT	usSizeOut/ usError:	Number of delivered bytes + 6 respectively error code in case of error.
USHORT	usUnused:	Reserved parameter.
UCHAR	usData[1440]	Data.

## 5.2 Functions

### 5.2.1 canbox\_init (Index 4)

Init of the CANbox. This function has to be called once before calling any other function. Otherwise all functions return the error CB\_NO\_INIT.

#### 5.2.1.1 Parameter

To None

From None

### 5.2.2 canbox\_reset (Index 5)

Closes all Identifiers, acceptance filters and interfaces. Sets the time stamp to zero. Clears the software buffer.

#### 5.2.2.1 Parameter

To CANBOX\_RESET\_EX

From None

### 5.2.3 canbox\_info (Index 6)

Delivers information about the device.

#### 5.2.3.1 Parameter

To None

From CANBOX\_DEVICE\_INFO Info structure for taking device information.

### 5.2.4 canbox\_set\_time\_stamp (Index 7)

Sets the time stamp. The time stamp has a resolution of 0.1 micro seconds.

#### 5.2.4.1 Parameter

To CANBOX\_TIME\_STAMP New value for the time stamp.

From None

## 5.2.5 canbox\_exit (Index 12)

Release of used resources. This function is to be called in the end.

### 5.2.5.1 Parameter

To None

From None

## 5.2.6 canbox\_open\_interface (Index 15)

Opens a CAN interface and configures it with the given parameters. The bit rate is given and the bit timing parameters are calculated from the given bit rate.

### 5.2.6.1 Parameter

To CANBOX\_INTERFACE Configuration for the interface.

From None

## 5.2.7 canbox\_open\_interface\_ex (Index 16)

Opens a CAN interface and configures it with the given parameters. Bit timing parameters are given directly.

### 5.2.7.1 Parameter

To CANBOX\_INTERFACE\_EX Configuration for the interface.

From None

## 5.2.8 canbox\_get\_interface\_state (Index 17)

Supplies the state of the CAN interface.

### 5.2.8.1 Parameter

To USHORT Zero based index of the interface.

From CANBOX\_INTERFACE\_STATE Structure for retrieving the interface state.

Alternativ with firmware 3.X or newer.

### 5.2.8.2 Parameter

To USHORT Zero based index of the interface.

From CANBOX\_INTERFACE\_INFO Structure for retrieving the interface state.



### 5.2.9 canbox\_start\_interface (Index 18)

Starts a stopped CAN interface.

#### 5.2.9.1 Parameter

To USHORT Zero based index of the interface.  
From None

### 5.2.10 canbox\_clear\_interface (Index 19)

Clears the data buffer of the interface.

#### 5.2.10.1 Parameter

To USHORT Zero based index of the interface.  
From None

### 5.2.11 canbox\_read\_interface (Index 20)

Reads the oldest data out of the data buffer of the interface.

#### 5.2.11.1 Parameter

To USHORT Zero based index of the interface.  
From CANBOX\_IDENTIFIER\_DATA Array of Identifier data for taking the received data.

### 5.2.12 canbox\_write\_interface (Index 21)

Sets the given data onto the CAN bus. Parameter ulld has to be set with the handle of the respective Identifier instead of the Id.

#### 5.2.12.1 Parameter

To CANBOX\_IDENTIFIER\_DATA Array of identifier data to be sent.  
From None

### 5.2.13 canbox\_stop\_interface (Index 22)

Stops a running CAN interface.

#### 5.2.13.1 Parameter

To USHORT Zero based index of the interface.  
From None

### 5.2.14 canbox\_close\_interface (Index 23)

Closes an open CAN interface.

#### 5.2.14.1 Parameter

To USHORT Zero based index of the interface.

From None

### 5.2.15 canbox\_open\_identifier (Index 25)

Opens an identifier and configures it with the given configuration.

#### 5.2.15.1 Parameter

To CANBOX\_IDENTIFIER Configuration of Identifier.

From CANBOX\_HANDLE Handle of the Identifier for accessing.

### 5.2.16 canbox\_read\_identifier\_buffer (Index 26)

Reads the last received data of an Identifier. The time stamp value is the actual time stamp value. This function should not be used if large amounts of data are to be exchanged between the CANbox and another connection participant, because the efficiency is reduced by the small packet size. Instead, the function canbox\_read\_interface with maximum amount of data should be used in this case.

#### 5.2.16.1 Parameter

To CANBOX\_HANDLE Handle of the Identifier.

From CANBOX\_IDENTIFIER\_DATA Structure for received Identifier data.

### 5.2.17 canbox\_read\_identifier\_actual (Index 27)

Reads the last received data of an Identifier. The time stamp value is the actual time stamp value. This function should not be used if large amounts of data are to be exchanged between the CANbox and another connection participant, because the efficiency is reduced by the small packet size. Instead, the function canbox\_read\_interface with maximum amount of data should be used in this case.

#### 5.2.17.1 Parameter

To CANBOX\_HANDLE Handle of the identifier.

From CANBOX\_IDENTIFIER\_DATA Structure for received identifier data.

### 5.2.18 canbox\_write\_identifier (Index 28)

Writes data of an Identifier to the CAN bus.

#### 5.2.18.1 Parameter

To CANBOX\_IDENTIFIER\_DATA Structure with identifier data to send.

From None

### 5.2.19 canbox\_close\_identifier (Index 29)

Closes an open CAN Identifier.

#### 5.2.19.1 Parameter

To	CANBOX_HANDLE	Handle of the identifier.
From	None	

### 5.2.20 canbox\_open\_filter (Index 30)

Opens an acceptance filter and configures it with the given parameters.

#### 5.2.20.1 Parameter

To	CANBOX_ACCEPTANCE_FILTER	Configuration for acceptance filter.
From	CANBOX_HANDLE	Handle of acceptance filter for accessing.

### 5.2.21 canbox\_read\_filter\_buffer (Index 31)

Reads the oldest data of an acceptance filter from the data buffer of the corresponding interface. This function should not be used if large amounts of data are to be exchanged between the CANbox and another connection participant, because it scans the whole interface data buffer for the oldest data of the filter. Instead, the function canbox\_read\_interface with maximum amount of data should be used in this case.

#### 5.2.21.1 Parameter

To	CANBOX_HANDLE	Handle of the acceptance filter.
From	CANBOX_IDENTIFIER_DATA	Structure for received acceptance filter data.

### 5.2.22 canbox\_read\_filter\_actual (Index 27)

Reads the last received data of an acceptance filter, the time stamp value is the actual time stamp value. This function should not be used if large amounts of data are to be exchanged between the CANbox and another connection participant, because the efficiency is reduced by the small packet size. Instead, the function canbox\_read\_interface with maximum amount of data should be used in this case.

#### 5.2.22.1 Parameter

To	CANBOX_HANDLE	Handle of the acceptance filter
From	CANBOX_IDENTIFIER_DATA	Structure for received acceptance filter data

### 5.2.23 canbox\_close\_filter (Index 32)

Closes an open CAN acceptance filter.

#### 5.2.23.1 Parameter

To	CANBOX_HANDLE	Handle of the acceptance filter
From	None	

### 5.2.24 canbox\_open\_sender (Index 13)

Opens a universal sender.

#### 5.2.24.1 Parameter

To	USHORT	Zero based index of the interface.
From	CANBOX_HANDLE	Handle of the universal sender for accessing

### 5.2.25 canbox\_write\_sender (Index 24)

Writes the data onto the CAN bus. The parameter ulld has to be set with the handle of the respective sender instead of the Id.

#### 5.2.25.1 Parameter

To	CANBOX_UNIVERSAL_SENDER_DATA	Array of Identifier data to be sent. In parameter hSender the respective handle of the universal sender has to be set.
From	None	

### 5.2.26 canbox\_close\_sender (Index 14)

Closes an open universal sender.

#### 5.2.26.1 Parameter

To	CANBOX_HANDLE	Handle of universal sender
From	None	

### 5.2.27 canbox\_read\_router\_config (Index 34)

Supplies the CAN router configuration.

#### 5.2.27.1 Parameter

To	USHORT	Zero based index of the interface
From	CANBOX_ROUTER	Structure for delivering the router configuration

### 5.2.28 canbox\_write\_router\_config (Index 35)

Configures the router using the given values.

#### 5.2.28.1 Parameter

To	CANBOX_ROUTER	Router configuration
From	None	

### 5.2.29 canbox\_read\_lan\_config (Index 36)

Supplies the actual EEPROM settings for the LAN connection.

#### 5.2.29.1 Parameter

To	None	
From	CANBOX_LAN_CONFIG	Structure for delivering the LAN settings

### 5.2.30 canbox\_write\_lan\_config (Index 37)

Sets the actual EEPROM settings for the LAN connection. The settings take effect after a restart of the CANbox.

#### 5.2.30.1 Parameter

To	CANBOX_LAN_CONFIG	LAN configuration
From	None	

### 5.2.31 canbox\_read\_wlan\_config (Index 38)

Supplies the actual EEPROM settings for the WLAN connection.

#### 5.2.31.1 Parameter

To	None	
From	CANBOX_WLAN_CONFIG	Structure for delivering the WLAN settings

**5.2.32 canbox\_write\_wlan\_config (Index 39)**

Sets the actual EEPROM settings for the WLAN connection. The settings take effect after a restart of the CANbox.

**5.2.32.1 Parameter**

To CANBOX\_WLAN\_CONFIG WLAN configuration  
From None

**6 Technical Data**

Parameter	min.	typ.	max.	Unit	Remark
Power supply	6	12	60	V	
Power consumption (depending on the used MAX modules)	1	5	12	W	min.: without modules max.: limited by DC/DC
Galvanic isolation		--		V	Only by suitable I/O module
Temperature	0	20	70	°C	
Dimensions					Complete device
Width		83		mm	
Height		33		mm	
Depth		113		mm	
Protection type		IP54			